

VW Golf MK8

LED Light Up Emblem

Installation Manual

Premium OEM-Style Installation Guide

Product Overview

This LED Light Up Emblem is designed specifically for the VW Golf MK8. It delivers an OEM-style appearance with factory-matched brightness and plug-and-play installation without coding.

Product Image Placeholder



Installation Overview

The installation process does not require front bumper removal. All work is performed from the front grille area. ACC radar calibration is not required if the sensor is not moved.

1,Required Tools

- 1 T25 Torx screwdriver
- 2 Plastic trim removal tool
- 3 Zip ties
- 4 Wire connectors

2,Important Notes

- 1 Turn off vehicle and remove key before installation.
- 2 Do NOT touch or move the ACC radar sensor.
- 3 No front bumper removal required.

3,Installation Steps

- 1, Use a T25 Torx to remove the screws securing the top of the grille on left and right.
Once the screws are removed, gently pull the grille forward.



Installation Overview



2, Behind the grille, locate and unplug 3 connectors. Left light bar connector, Right light bar connector and ACC radar-related connector. Press the locking tab and then Pull the connector straight out.



Installation Overview

3, Connect LED emblem black wire → vehicle brown wire (ground), Connect LED emblem red wire → vehicle power wire (+), then Crimp firmly to ensure a solid connection.



4 Test LED emblem before final installation.

.

4.1, Plug the LED emblem into its connector.

4.2, Leave the emblem outside the grille

4.3, Turn the ignition on

4.4, Check if the emblem lights up

Installation Overview



5 Remove factory emblem from rear of grille. Use a plastic trim tool or flat screwdriver to push the clips outward.



Installation Overview

6, Install LED emblem and route wiring carefully.

Pull the wire gently from the back then Press the emblem firmly until it clicks into place.



Installation Overview

7 Secure wiring and reconnect all plugs.

7.1 Secure excess wiring using zip ties

7.2, Ensure wiring: Does NOT block the ACC radar & Does NOT touch moving components

7.3, Reconnect all factory plugs

7.4, Align arrows on connectors, push in, then lock tabs



www.lea.com

Installation Overview

8 Reinstall grille and test final lighting.

8.1, Align the grille with the front bumper,

8.2, Press evenly to engage all clips,

8.3, Reinstall all T25 Torx screws,

8.4, Start the vehicle and check final lighting



www.10

Final Notes

- No coding required • Compatible with ACC radar systems • OEM-style brightness and appearance
- Designed for VW Golf MK8 only

For best results, ensure all wiring is secured away from moving parts and sensors before completing installation.

www.ledcarembblem.com